

PRALINE WAFERS

28(?) graham ^{wafers} (crackers)

1 C. butter

1 C. firmly packed brown sugar

1 C. sliced almonds

Arrange graham wafers on lightly buttered 15 x 10" (?) cookie sheet. Melt butter in saucepan, stir in sugar, bring to boil, boil for 2 minutes. Stir in almonds &

spread over crackers.

Bake @ 350° 8-10 minutes or until bubbling. Cut wafers in half & remove from pan while still warm. Makes about 56(?).